DCP-L2500D / DCP-L2520D / DCP-L2520DW / DCP-L2540DN / DCP-L2540DW / DCP-L2541DW / MFC-L2700D / MFC-L2700DN / MFC-L2700DW / MFC-L2701D / MFC-L2701DW / MFC-L2703DW

Quick Setup Guide



Not all models are available in all countries.





Unpack the machine and check the components





Drum Unit (Pre-installed)

Inbox Toner

Cartridge



AC Power Cord (only for certain models)



Telephone Line Cord (For MFC models)



Quick Setup Guide



CD-ROM



Product Safety Guide



Basic User's Guide (only for certain models)

Read the Product Safety Guide first, then read this Quick Setup Guide for the correct installation procedure.


NOTE:

- The components included in the box and the AC power plug may differ depending on your
- The illustrations in this Quick Setup Guide are based on the MFC-L2700DW.
- · You must purchase the correct interface cable for the interface you want to use.


We recommend using a USB 2.0 cable (Type A/B) that is no more than 2 metres long. **Network cable**

Use a straight-through Category 5 (or greater) twisted-pair cable for 10BASE-T or 100BASE-TX Fast Ethernet Network.


Remove the packing materials and install the toner cartridge



Load paper in the paper tray



Connect the power cord and turn on the machine



Select your country/language (Initial setup only)

After turning on the machine, you may be required to set your country or language (depending on your machine). If required, follow the on-screen instructions.

Select your language (If needed) (Only for certain models)

- 1. (DCP model)
 - a. Press Menu.
 - b. Press ▲ or ▼ to display General Setup, and then press OK.
 - c. Press \blacktriangle or \blacktriangledown to display Local Language, and then press **OK**.
- (MFC model) Press Menu, 0, 0.
- 2. Press ▲ or ▼ to select your language, and then press **OK**.
- Press Stop/Exit.

Connect the machine to your computer/mobile device


- Windows® PC with a CD-ROM drive, go to step 6A
- Windows® PC without a CD-ROM drive, go to step 6B
- Macintosh, go to step 6B
- Mobile device users with a WPS/AOSS™-supported access point/router, go to step 6C







Configuration using the CD-ROM (Windows®)



NOTE:

If the Brother screen does not appear automatically, go to Computer (My Computer). (For Windows® 8: click the (File Explorer) icon on the taskbar, and then go to Computer.) Double-click the CD-ROM icon, and then double-click start.exe.



Follow the on-screen instructions to continue installation until either the Connect the machine or the Connection Type screen appears.


■ Connect the machine: Follow the on-screen instructions to continue installation.



■ Connection Type:







For USB Connection

For Wired Network Connection
Connect a network cable first.

For Wireless Network Connection
We recommend preparing a USB cable
to use temporarily during the wireless
setup.

Follow the on-screen instructions to continue installation.




NOTE:

If connection is unsuccessful, repeat this step.



(For Macintosh) solutions.brother.com/mac

Wireless Network Connection



[Recommended]
Select this option if you have a USB cable to use temporarily for wireless setup.

Select this option if you do not have a USB cable.

Follow the on-screen instructions to continue installation.



Finish

NOTE:

If connection is unsuccessful, repeat this step

6B



Configuration without using the CD-ROM (Windows® without CD-ROM drive or Macintosh)

Download the full driver and software package from the Brother Solutions Center. (For Windows®) solutions.brother.com/windows


After you download the driver and software package, follow the on-screen instructions until the **Connection Type** screen appears. Refer to **6A** *Configuration using the CD-ROM (Windows®)*.





One-push wireless setup for mobile devices (Wireless models only)

If your wireless LAN access point/router supports automatic wireless (one-push) setup (WPS/AOSS™), you can set up your machine without using a computer.





Print and scan using your mobile device

Download "Brother iPrint&Scan" to start using your machine with mobile devices.



solutions.brother.com/ips