


Product and controls overview

EN Product and controls overview


- 1. Forward / Backward
- 2. Volume up / Volume down
- 3. Answer call / End call
- Reject call
- 5. Voice control
- 6. Play / Pause



Product and controls overview

EN Product and controls overview

- 1. Battery level button
- 2. Charging slot for left earpiece
- 3. Battery level LED indicators
- 4. Charging slot for right earpiece





Quickstart guide

1. Power on

To power on, place the earpieces in the charging case then take them out of the charging case, both earpieces at the same time. The LED on toth earpieces will flash in white. Once the two earpieces have connected to each other, the LED on the left earpiece will turn off and the LED on the right earpiece will flash in red and white as the earphones enter pairing mode automatically.

2. Pairing

To pair, go to Bluetooth® settings on your device and select
"JAYS m-Seven True Wireless". The LED on the right earpiece will turn off upon
a successful connection.

3. Wear and use

Select a pair of ear tips that fits your ear the best. Place the earpiece marked with "L" on the back in your left ear. Place the earpiece marked with "R" on the back in you right ear. Once you find a comfortable fit follow the instructions of the touch contols on the previous pages.

4. Charging

When the LED on the earpieces flash in red, the battery level is running low. To charge, place both the earpieces in the charging case, the charging will begin automatically. The charging is indicated by the LED flashing in red on both earpieces. When the LED turns off, the earphones are fully charged.

The battery level of the charging case is indicated by the four white LEDs on the front of the charging case. Press the button on the back of the charging case to check the battery level. Charge the charging case by connecting the included cable to the bottom of the charging case and you restrified USB power output. A full 100% charge will take around 2.5 hours (depending on temperature and chargeer).

One light, 25% battery. Two lights, 50% battery. Three lights, 75% battery. Four lights, 100% battery.

Charge the charging case by connecting the included cable to the USB-C port on the bottom of the charging case and any certified USB power output. A full 100% charge will take around 2.5 hours (depending on temperature and charger).

5 Power off

Place the earpieces in the charging case and they will turn off automatically. If the Bluetooth® on the paired device turns off, the earphones will turn off automatically after 3-5 minutes.

Jays Group AB Nellickevägen 22, 412 63 Gothenburg, Sweden

www.jaysheadphones.com



