




Avaya L159 Headset Quick Reference Guide

Release 1
Issue 1
December 2018
© 2018, Avaya Inc.
All Rights Reserved.

Avaya L159 Headset

Thank you for purchasing the Avaya L159 Headset. Read the instructions carefully before using this product, and retain them for future reference.

Part overview



- 1– Headband
- 2– Speaker
- 3– Microphone
- 4– Busy LED
- 5– Avaya L100 Touch Controller with Bluetooth
- 6– USB connector

Features

- Rotating microphone boom arm that can be worn on the left or right side
- Adjustable headband and microphone that provides a customized fit
- High resolution audio
- Bluetooth
- Touch sensor with primary functions

Connecting the headset to a personal computer

1. Plug the USB connector.
 - At the first instance, the taskbar displays a pop-up message. The message includes information that the headset is connected and ready for use.
 - The Play/Pause key ►|| on the headset changes its status to ►||.
 - The Play/Pause key changes its status only if you have installed the Avaya Setup Tool on your computer.
2. **(Optional)** If you are using Windows 7, at the first plug in, set the Avaya L159 Headset as the default device.
 - a. Navigate to **Control Panel > Sound Settings**.
 - b. Select the Avaya L159 Headset.

Bluetooth

The headset has built-in Bluetooth for pairing the headset with a mobile device. When the headset is not paired with a mobile device, the Bluetooth status remains off.

Pairing the headset with a mobile device

1. On the Avaya L100 Touch Controller with Bluetooth, press and hold the Bluetooth logo for 5 seconds. You can hear the voice prompt “Pairing,” and the Bluetooth indicator starts flashing alternately blue and red.
2. Turn on Bluetooth on your mobile device.
3. Search for nearby Bluetooth devices and select the headset. You can hear the voice prompt “Connected,” and the Bluetooth indicator changes from to solid red.

Your mobile device is now connected with the headset.

For more information, see [Toggling between the personal computer and mobile device](#) on page 3.

If your mobile device is out range of the headset, then the Bluetooth logo starts blinking.

Adjusting the headband

All Avaya corded headsets have a flexible and adjustable headband.

1. Place the headband on your head. You can place the speaker with microphone on your left or right ear as per your own comfort.
2. Adjust the headband for a comfortable fit.




Positioning the microphone

For optimal sound quality, position the bendable boom arm in front of your mouth at a distance of 2–3 cms.



Rotating the bendable boom arm

Rotate the boom arm as required up to maximum 360°.



Avaya L100 Touch Controller with Bluetooth

You can control different functions of the headset with the Avaya L100 Touch Controller with Bluetooth, which provides the following touch functions:



Callout	Description
1	Mute key to mute or unmute the microphone
2	Volume key to increase or decrease the volume
3	Softhook key to answer or end a call, double press to hold an active call, and double press to redial last number
4	Bluetooth key to switch between the mobile device and the personal computer, double press to hold an active call, and double press to redial last number
5	Play/Pause key to play, pause, and continue the media

Enabling and disabling the key lock

You can lock and unlock all keys on the Avaya L100 Touch Controller with Bluetooth. When key lock is enabled and you receive or make a call, then the key lock function gets disabled and reverts back to the previous state after you hang up.

On the Avaya L100 Touch Controller with Bluetooth:

- To enable the key lock, press and hold the logo for 10 seconds.

You can hear a short beep followed by a voice prompt: “Key locked”. The logo on the Avaya L100 Touch Controller with Bluetooth glows and dims repeatedly.

- To disable the key lock, press and hold the logo for 10 seconds again.

You can hear a short beep followed by a voice prompt: “Key unlocked”.



Operating the headset

You can listen to music or any other audio when:

- You connect the headset to your personal computer.
- You are not making or receiving a call.

Adjusting the volume

1. On the Avaya L100 Touch Controller with Bluetooth, touch the Avaya branding:

- Swipe up to turn up the volume.



- Swipe down to turn down the volume.



2. You can also control the volume from your personal computer.

Answering and ending a call


On the Avaya L100 Touch Controller with Bluetooth:

1. To answer a call, touch the Softhook key.



- To end an active call, touch the Softhook key again.

Muting and unmuting a call

You can mute and unmute a call by using any of the following ways:

- On the Avaya L100 Touch Controller with Bluetooth, touch the Mute/Unmute key  to mute and unmute a call.



- When you mute an active call, the  logo turns red and you hear a short beep followed by a voice prompt “Microphone muted”.
- When you unmute a call, the  logo is turned off and you hear a short beep followed by a voice prompt “Microphone unmuted”.

- Press the tip of the boom arm to mute and unmute a call.



Enabling and disabling the busy LED indicator

The headset has a busy LED indicator on the Avaya L100 Touch Controller with Bluetooth. Busy LED indicates whether you are ready to make or receive call.




On the Avaya L100 Touch Controller with Bluetooth,:

- To enable the busy LED, press and hold the logo for 2 seconds.
You hear a voice prompt: “Busy enabled”.
- To disable the busy LED, press and hold the logo for 2 seconds again.
You hear a voice prompt: “Busy disabled”.



Playing and pausing an audio

When you wear the headset, you can hear any audio from the preferred audio player.



- On the Avaya L100 Touch Controller with Bluetooth, touch the Play/Pause key  to play and pause the audio.



- You can also play and pause the audio from your mobile.
If you receive a call when listening to the audio, the computer or mobile device turns off the audio automatically and you hear an incoming call.
- If you use your computer to make or receive calls and want to listen to a streamed audio, then do the following.

- Navigate to **Control Panel > Sound > Communication**.
- Select the preferred volume option.

Toggling between the personal computer and mobile device

On the Avaya L100 Touch Controller with Bluetooth, press and hold the Bluetooth logo for 2 seconds.

You can hear a beep and the Bluetooth logo turns from blue  to red .

- Blue  indicates that the headset is active on the mobile device.
- Red  indicates that the headset is active on the personal computer.

Making a call on the mobile device when the headset is connected to a personal computer

When you make a call from your mobile device, you can choose to make a call using the headset or without the headset.

To make a call by using the headset ensure that the headset is paired with the mobile device and the Bluetooth logo on the Avaya L100 Touch Controller with Bluetooth is blue.

- Dial the number on your mobile device and make a call.
- To redial the last number, double press the Bluetooth logo .

Receiving a call on the mobile device when the headset is connected to a personal computer

When you receive a call on your mobile device, you hear beeps in your headset and the Bluetooth symbol starts blinking blue.

Press the Bluetooth logo to switch the headset to the mobile device.

The call is automatically answered.

When you are listening to audio on your mobile device and you want to receive or make a call, the:

- Phone pauses the audio track
- Play/Pause key turns orange

Headset compatibility

To check the compatibility of the headset with other products, see <http://support.avaya.com/CompatibilityMatrix/Index.aspx>.

Care and safety information

- To avoid damage to hearing, do not listen at high volume for a prolonged period.
- Clean the headset only with a dry and soft cloth.
- Always keep the headset dry and do not expose it to low and extreme temperatures.
- Not for domestic use.